

Factory Setup:

In the event that it is desired to restore all of the defaults that came from the factory perform the following:

1. Access the service menu using the service passcode (5991)
2. Press the Service button. The display will alternate between showing the “service contact information” and “Press Select (5) for Menu”.
3. Press Select (5).
4. Press the down arrow (8) until “Factory Setup” is visible. Press the Select (5) button to select this option.
5. To completely reset the factory default settings, press the Select (5) button.
6. Confirm resetting factory defaults by pressing the Select (5) button again.
7. After the defaults have been reset, the touch pad will return to its locked position.
8. Press the service button at any time to cancel the process.

Resetting to factory setup will reset the total cycle count on the unit.

All settings will be restored to factory defaults including radio modules (either WiFi or RF Remote) and Feature Controller if installed.

WiFi Connect at connect.coverstar.com:

If your device was supplied with a WiFi connect wireless radio you will have the ability to enable online alerts via email and text messaging if you connect the touch pad to a wireless internet connection utilizing 802.11b/g technology. To connect the touch pad please refer to the WiFi connect portion of this document above.

The Coverstar WiFi touch pad is designed to automatically send alerts via text or Email, using your home WiFi network. In order for the touch pad to perform as intended, the touch pad unit must be installed in accordance with Coverstar's instructions, be connected to a home power source, and a home WiFi network must be set up and functioning correctly, with a continuous WiFi signal to the pool area. Setup and maintenance of these items is the sole responsibility of the homeowner and failure to do so will prevent the Coverstar touch pad from performing as intended.

Please note that some home WiFi routers may be out-of-date and may require updated security protocols in order to function correctly. The Coverstar WiFi touch pad utilizes 802.11b/g technology and supports open, WPA-PSK (TKIP) and WPA2-PSK authentication technologies. A WPS protocol can be used to establish an easy and secure wireless setup on supporting WPS enabled routers. Alerts can be received using any phone with email and SMS text capability. **IMPORTANT: While the Coverstar touch pad can be used to enhance a homeowner's information about the pool safety cover, it DOES NOT guarantee safety in or around your pool. Safety covers should remain in the closed position whenever the pool is not in use. Latham Pool Products and its authorized dealers and distributors always recommend multiple layers of protection, including parental supervision, fences, safety covers, alarms or other means to prevent access to a pool when it is not in use. THERE IS NO SUBSTITUTE FOR CONSTANT ADULT SUPERVISION WHENEVER CHILDREN ARE IN OR AROUND ANY BODY OF WATER.**

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.