

Mounting and Configuration Instructions for Remote Touch Pad Applications

Connection Notes:

- * Review wiring instruction document number L9669 for proper installation of Remote Host Touch Pad or L9665 for proper installation of Feature Controller Host Devices.
- * Remote Touch Pad is intended for fixed mounting operation only! **For safety please mount the remote touch pad in a fixed location where 100% of the pool surface is visible.**
- * Pool calibration should be performed on the remote host touch pad in situations where the remote is being connected to a remote host touch pad.
- * If purchasing the remote with a remote host or feature controller the device should already be synchronized with the host device from the factory.
- * If the remote needs to be synchronized to a host do so by doing the following.

On the Host Device:

For Feature Controllers press the RF Sync Button on the control board.

For Host Touch Pads.

1. Log in to host device with service code.
2. Select Press for Service.
3. Select 5 for menu.
4. Use up and down arrows to select User Defaults.
5. Use up and down arrows to select Connect Remote.

You will have 4 minutes to connect a remote after initializing on either the feature controller host or the touch pad host. If “Connect Remote” option is not found ensure device is setup as a remote host under the “Remote Module” Option in the “User Defaults” Menu.

On the Remote Device:

1. Log in using the service code.
2. Select “Press for Service” and Select 5 for menu.
3. Select “User Defaults.”
4. Select “Remote Module.”
5. Set to “Remote” and Select 5.
6. Follow On screen instructions.

* Use only (3) AA Alkaline Batteries. Do not mix battery types! Do not use old batteries with new batteries.

Please see programming instructions for further details.

Troubleshooting Tips:

- * If the power does not come on the display check that batteries are installed and plugged into the back of the remote touch pad.
- * If you receive a “No Host Found” message when the touch pad comes on, check to make sure that the host unit is turned on. Let the unit power back off and retry. If message still occurs reset the radio module and resync the device.

* Radio waves work best when in line of site of antennas. If you are having intermittent or no operation with your device, try to reposition the devices such that they are line of site to each other. Avoiding metal and concrete walls will also help with intermittent signals.