


Installation Instructions

Flush Deck Aluminum Lid Kit

IMPORTANT: The parts shown in this kit are for the 14 inch flush lid kit. Kits for a 12-1/2 inch and 15-1/2 inch kits are also available.

The *QuickAttach* system that is also shown in these instructions are also based on using a 14 inch flush lid kit. When installing the *QuickAttach* system in the other sizes of flush lid kits, the pulley brackets width will need to be adjusted to fit the width of that flush lid kit.




We make it strong. We make it easy.™
COVERSTAR

L6950 Ver. 2.2 10.22.18 bm

Aluminum Lid Kit Applications

The Coverstar flush deck lid kit can be used for either under track or recessed topg track pool cover systems with curved cover track. This system can also be installed in housings made of concrete or other durable materials as long as they are the required dimensions. See *assembly instructions on reverse side*.

For an integrated solution, use the Coverstar polymer housing kit (part # A2400, below), which is engineered specifically for the flush deck lid system.



Tools Required

10" Chop Saw w/ carbide blade, cordless drill, Optional for drilling into concrete: Hammer Drill with 1/4" masonry bit.

Flush Deck Aluminum Lid Kit Parts

Kit **A2420** (for pools up to 20' wide) includes all the parts necessary to install the lid system for all Coverstar systems. Call your distributor for information on larger pool sizes.

Qty	Part #	Description
1. 4	A2409	Lid bracket with bolt for 309 riser panel (X0944) each SS for 14in box
2. 2	A2410	Riser Box End Assembly 309 for 14 in box
3. 1	M9354	Riser panel 309 cut to fit coping transition profiles 40in long notch on both ends
4. 10	M9356	Riser panel 309 fixed height hook 2 in long
5. 1	X0048	Lid Panel Flush (1 in x 6 in) 24'
6. 1	X0669	Lid Panel Flush (1 in x 7.5 in) 24'
7. 1	M0944	Flush Lid Riser 309

A2414 Flush lid 309 Hardware Kit

8.	A2414	Flush Lid 309 Hardware Kit (All of the parts for this hardware kit will be shown in picture number 8 instead of separate pictures)
1	A1920	30 pk - Screw HHW tek #10 x 1 in zinc (H9614)
1	A2117	4 pk, Hex head Bolt 1/4 - 20 x 5 with 90 degree bend (M9122)
1	A2484	4 pk. Washer flat 1/4 in SS (H0002)
1	A2500	8 pk. 1/4 - 2- Nut (H0277)
4	M9351	Splice for riser panel 309


QuickAttach Mechanism Mounting Kit

9.	M9467	QuickAttach anchor plate for ME pulley side
10.	M9468	QuickAttach anchor plate for ME water side
11.	M9469	QuickAttach anchor plate for NME pulley side
12.	M9470	QuickAttach anchor plate for NME water side
13.	M9463	QuickAttach mechanism mounting plate - ME pulley side
14.	M9464	QuickAttach mechanism mounting plate - ME water side
15.	M9465	QuickAttach mechanism mounting plate - NME pulley side
16.	M9466	QuickAttach mechanism mounting plate - NME water side

Optional Lid Decender Kits

17. A1111 Descender Kit BULLNOSE for flush lid panels up to 22 ft
18. A1110 Descender Kit ROUNDED for flush lid panels up to 22 ft
19. A1112 Descender Kit INCLINED for flush lid panels up to 22 ft
20. A1752 Descender Kit NO PROFILE (Metal C-Cap) for flush lid panels up to 20 ft track space







1 Check the inside width of the cover housing. Make sure it matches the width of the flush lid kit that was ordered.




2 Place the preassembled boxed riser ends (A2410) at each end of the housing.



3 Measure across the back of the housing between the boxed ends. Cut a length of the riser (X0944) to fit in this opening.




4 Insert splices (M9351) in the splice channel of the riser so they will extend part way into the splice channel of the of the riser and box end.



5 Insert the fixed height hooks (M9356) into the channel on the outside of the riser. These hooks will rest on the housing and set the height of the riser 4 inches above the housing.



6 Using the piece of riser that is 40 inches long and notched at each end (M9354), cut the riser to fit on the front side of the housing for the motor and non-motor ends. The cover guide will pass through the notches in the riser.



7 If using a Coverstar Encapsulation with coping, install the transition pieces that will fit between the riser panel and the encapsulation/coping.




8 Secure the riser to the housing by screwing 1 inch self-tapping screws (H9614) through the riser and into the housing. Make sure the top of the riser is flush with what will be the finished deck height.



9 Install the lid brackets into the riser along the back of the housing. Place a level on the brackets and level them by adjusting the bolt at the bottom of the bracket.




10 Measure from the inside of one riser boxed end to the other in order to determine the total lid length. Cut the lid panels to this length.



11 If a lid descender is being used, cut the descender to fit across the front of the lid between the coping. Also, cut the flat no profile descender to fit on the motor and non-motor ends of the lid. If a profile descender is not being used, use the flat no profile descender (A1752) across the entire lid.



12 Slide the two sections of lid together. Slide the descenders on the front side of the lid. Position the lid in so it rests on the lip of the riser and on the lid brackets. Make sure the lid is in place when the concrete is poured. The lid can be masked off or turned upside down to keep it clean during the concrete pour.




13 The *QuickAttach* Mechanism Mounting Kit includes (4) anchor plates and (4) mechanism mounting plates. These plates are labeled according to the location in the cover housing where they will be mounted:
 Motor End Water Side
 Motor End Pulley Side
 Non Motor End Water Side
 Non Motor End Pulley Side




14 Position the anchor plate into the top channel of the riser by inserting it at an angle so the top of the anchor plate goes into the channel first, and then move the bottom of the plate into the channel. Repeat this process for the other anchor plates.



15 Insert the *QuickAttach* mounting plate over the appropriate anchor plate.




16 Install the cross braces over the pem studs in the *QuickAttach* brackets at both the motor and non-motor ends of the housing. These cross braces will maintain the correct width between the *QuickAttach* mechanism mounting plates during the concrete pour. Secure using 1/4 - 20 nylock nuts. These cross braces will be removed when the mechanism is installed.




17
Install 1/4 - 20 nylock nuts onto the (2) pem studs in the anchor plates. Do not tighten these nylock nuts down at this time so the mounting brackets can slide side to side to position the mechanism in the correct location.

Repeat this process for each of the QuickAttach mechanism mounting plates


NOTE: The QuickAttach mechanism mounting kit includes (8) 1/2 inch bolts that will be used when the mechanism is mounted in the housing. If the mechanism is being mounted at a later date, save these bolts and use them to secure the mechanism to the mounting plates.



18
Both, the Eclipse and Aluminum mechanisms are being shipped with the pulley brackets on both the motor end and non-motor ends already set at the correct width and height for the QuickAttach system.



19
Turn the motor end of the mechanism upside down to install the mounting feet. For the Eclipse mechanism, use the top hole in the mounting feet. For the aluminum system, use the second hole from the top on the mounting feet.



20
Install the mounting feet on the non-motor end of the mechanism. For the Eclipse mechanism, use the top hole to mount the feet. For the aluminum system, use the fifth hole down from the top.


NOTE: It is important to use the mounting feet so the mechanism is securely mounted in the cover housing.




21
Drop the motor end of the mechanism into place by aligning the slots that are in the bottom of the pulley brackets with the pem studs in the mounting plates and sliding it into place.




22
Install the non-motor end of the mechanism so the slots in the pulley brackets slide over the pem studs in the mechanism mounting plates.




23
Attach the roll-up tube to the motor and non-motor ends of the mechanism using the hardware provided.




24
To position the mechanism in the correct location, use a length of rope to make sure it will travel straight from the cover guide to the pulleys on the mechanism. It is very important that the roll up tube be centered between the cover guides.




25
Tighten the nylock nuts to secure the mounting plates to the riser and the mechanism pulley brackets to the mounting plates.



26
The mechanism mounting plates have threaded holes in them that line up with the mounting holes in the pulley brackets. Insert 1/4 - 20 x 3/4 inch bolts into these holes and secure the motor end of the mechanism to the mounting plates.



27
Secure the non motor end of the mechanism to the mounting plates using the 1/4 - 20 x 3/4 inch bolts.



28
For the aluminum system, use a 3/16 drill bit to drill through the holes in the cross braces. For the aluminum and Eclipse system, use 1/2 inch screws and nylock nuts provided to secure the cross braces together. Repeat this process on the non motor end of the mechanism.