










Unstitch the webbing from the cover about an inch and a half past the damaged area on each side.



Cut your webbing patch to fit the area that has been unstitched, lay your patch into place and mark it's position on the old webbing.



Cut webbing away from the rope within the marked area underneath the patch. This is crucial to ensure the rope will fit through the track and guides.



Line up the patch with the cut area so that there is no material overlapping around the rope. Begin to sew a seam next to the rope, keep the webbing as tight to the rope as possible. Once the patch is sewn to the rope you will then re-sew the webbing to the cover, be sure to keep the webbing spaced equally. You will then sew a zig-zag seam over where the patch meets the old webbing to avoid the patch catching on the cover guide.

